

## BACKPACK BILLBOARD ASSEMBLY HARDWARE



- A. Backpack with Mount
- B. Print
- C. Support Poles



## BACKPACK BILLBOARD ASSEMBLY



1. Slide each Support Pole (C) together until snug. If poles are not fitting, try using the opposite side of the pole or changing the order of the poles. (There is only one correct order for each Support Pole).
2. Insert all four of the Support Poles (C) into the mount on the backside of the Backpack (A) until snug. Position the hooks facing towards you.



3. Once all four Support Poles (C) are mounted, locate the grommets at the corners of the Print (B) and attach to the hooks on the Support Poles (C). Mounting print to top hooks first is suggested.