

POP UP BACKDROP COLLAGE


Assembly Instructions

ASSEMBLY HARDWARE




- A. Frame
- B. Carrying CaseC. Pop Up Backdrop
- Light Halogen*
- D. Pop Up Backdrop Light LED*
- E. Light Cord*
- F. Pop Up Stabilizing Foot - Set of 2*
- * Optional





ASSEMBLY



NOTE: Additional people may be required for larger displays.


- **1.** Place fully collapsed frame (A) down onto the ground with the print side facing up. Expand the frame (A) outwards.
- Connect all exposed plastic connectors, located within the frame (A), by pressing each end together until the plastic tab "snaps" into place.
- **3.** Install panels by placing button holes over pins on frame hubs.

OPTIONAL: If Pop Up Lights are NOT being used, skip to STEP 7.

- **4.** Slide the base of the Pop Up Light Halogen (C) or Pop Up Light LED (D) onto one of the desired light mounts located on the top-front of the frame (A). Repeat with second light, if two are being installed.
- **5.** Connect the light cord (E) into the base of the light(s).
- **6.** Stand the fully assembled frame (A) vertically and adjust the angle of the lights. Plug in the light cord (E) and switch the light(s) on. Connect any remaining plastic connectors within the frame (A).
- **7.** If frame (A) needs leveling, adjust the height of the leveling feet located at the bottom-front of the frame (A).

POP UP BACKDROP COLLAGE

ATTACHING STABILIZING FEET



- 1. Assemble the frame and lay it down.
- 2. Remove the screw from an adapter. Attach an adapter to the bottom of the frame. There will be open slots where the adjustable feet (F) are located. Insert the adapter, with the adjustable foot facing out, into this slot. Secure it into the slot by inserting the screw and tightening it with a Phillip's head screwdriver.
- **3.** Install the foot by placing the large portions of the open sections over the adjustable feet. Pull it down and secure it to the frame by tightening the feet.